

AF-350 Maintenance Instructions

Maintenance should be performed a minimum of once daily.


1. Remove intake hood by lifting upward.



2. Slide the air cleaner out of the cabinet. Loosen the air cleaners (round) clamping knobs to remove the inlet cover.



3. Remove the baffle pre-filter. Hand wash in dishwashing detergent and rinse all 3 Parts – the intake hood, inlet cover & baffle pre-filter. Pieces can be run through the dishwasher, as well.



- Carefully remove the rigid cell primary filter. Observe the condition of filter. Look for any contaminants that have damaged or restricted the airflow. If there is any torn media, or damage is found due to excessive grease, replace the filter.



- Carefully remove the activated carbon panel final filter. Observe the condition. The filter can be shaken to clean out any loose dirt or liquid. If there is excessive odor, torn filter media, or excessive grease, replace the filter.



- Make sure all pieces are dry before reinstalling.
- Replace the cleaned, dry filters in reverse order of removal. Connect the inlet cover and be sure to tighten the clamping knobs on each side of the air cleaner. Return the air cleaner to its original position in the cabinet. Reinstall the intake hood.



Questions?

***Contact Our Technical Team
By Calling 1-630-527-8600***